


**RUNNING BOARDS**  
**07-18 15-3500 SILVERADO/SIERRA REGULAR CAB**  
**INCLUDES DIESEL W/DEF**

**PARTS LIST:**

2	Aggressive Running Boards	9	8-1.25mm x 25mm Hex Bolts
3	Mounting Brackets (use for left or right)	17	8mm x 24mm x 2mm Flat Washers
1	Passenger/right Front Upper Bracket (all incl. DEF)	17	8mm Lock Washers
1	Passenger/right Front Lower Bracket (all incl. DEF)	1	8mm Bolt Plate
7	8-1.25mm Clip-On Nuts	1	8mm Nylon Lock Nut (use w-bolt plate)
4	8mm Double Bolt Plates	8	8mm Hex Nuts



**PROCEDURE:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED. ON MODELS WITH DEF TANK, SELECT A FLAT, LEVEL AREA FOR INSTALLATION. MAY REQUIRE CUTTING.**

1. Start the installation under the driver side of the vehicle. Locate the 3 tabs along the bottom edge of the body, (pinch weld). Mounting Brackets will bolt to the 1st and 2nd mounting tabs, **(Figures 1 & 3)**. Directly above each tab is a top mounting location on the side of the body panel. Hold a Bracket up in place to help determine the mounting holes to use along the body.
2. Determine the correct procedure for your model year and each Bracket location.

**Bottom mounting location on the edge of the pinch weld.**

**Flat tab on pinch weld with factory installed weld nut:**

Thread hex bolt into weld nut from the backside-down to clear paint from threads, **(Figure 2)**.

**Flat tab on pinch weld with hole:**

Select (1) 8mm Clip Nut. Slide the Clip Nut over the tab with the nut facing up behind the tab, **(Figures 1, 3 & 4)**. Line up threaded nut with hole in the tab. Repeat for each mounting location.

**Locate top mounting location on the back side of the body panel.**

**Models with factory installed threaded insert in body panel:**

Thread 8mm Hex Bolt into threaded insert to clear paint as required, **(Figure 2)**.

**Large and small hole in side of body panel:**

Remove the rubber plug from the larger hole, **(Figures 1, 3 & 4)**. Select (1) 8mm Clip Nut. Slide the Clip Nut into the larger hole. Line up the threaded nut with the smaller hole, **(Figure 4)**.

3. Select (1) Mounting Bracket. **NOTE:** (3) Brackets are universal and will fit all left side and only rear location on right side. Attach the Mounting Bracket to the Clip Nuts and/or the factory threaded holes with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, **(Figures 5, 6 & 9)**. Snug but do not fully tighten the hardware.
4. Repeat **Steps 1—3** to install the rear driver side Bracket, **(Figures 5, 6 & 10)**.

**RUNNING BOARDS**  
**07-18 15-3500 SILVERADO/SIERRA REGULAR CAB**  
**INCLUDES DIESEL W/DEF**

5. Carefully unwrap (1) Running Board. Place the Running Board on top of the (2) Brackets. Locate the channels in the bottom of the Running Board. Select (2) 8mm Double Bolt Plates, **(Figure 7)**. Insert the Bolt Plates into the channels in the bottom of the Running Board closest to the Brackets, **(Figure 8)**. Lift the Running Board up and guide the studs down through the Brackets.
6. Attach the Running Board to the Mounting Brackets with the included (4) 8mm Flat Washers, (4) 8mm Lock Washers and (4) 8mm Hex Nuts, **(Figures 9 & 10)**. Do not tighten at this time.
7. Level and adjust the Running Board as desired and tighten all hardware.
8. Move to the passenger side of the vehicle. On the passenger side, determine if the vehicle is equipped with a plastic diesel exhaust fluid (DEF) tank, **(Figures 11 & 12)**.

**Models without DEF tank, skip to Step 9.**


**Models with DEF tank:** The tank sits close to the side of the body. With specialized tools, the passenger front upper and lower Bracket can be installed but room is limited. It may be easier to drop the tank down to access the inner side of the body panel for upper bracket installation. Tank will not need to be removed, only dropped down for access to mounting location. **IMPORTANT:** If tank is full, it will be very heavy and assistance is highly recommended to avoid injury or damage to the vehicle or the tank. It is recommended that installation is performed when the DEF tank is low on fluid before dropping the tank.

- a. On models with plastic lower tray under the tank, remove (3) hex bolts attaching the tray to the frame, **(Figure 11)**, and remove the tray. **2017 2500/3500 models:** Remove the (4) hex bolts attaching the plastic cover to DEF tank, **(Figure 12A)** and remove plastic cover, **(Figure 12B)**.
  - b. Release the tank filler hose. Release the plug for the sending unit on the top of the tank.
  - c. Support the tank with a floor jack. Place a smooth flat surface, (wooden block for example), between the floor jack and the tank to avoid damaging the plastic tank. Do not push up on the tank; only support the weight of the tank with the jack.
  - d. Remove the (2) bolts securing the tank straps to the vehicle, **(Figure 13)**. Tilt the straps to release from the brackets. Slowly lower the tank until the top of the tank is almost visible. Use blocks or stands to support the tank while installing the front Upper and Lower Brackets.
  - e. Proceed to **Step 9**.
9. Locate the first tab on the edge of the pinch weld, **(Figures 1, 15 & 17)**. Select the Upper Bracket, **(Figure 14)**. Repeat **Steps 2 & 3** to attach the passenger front Upper Bracket to the side of the body panel, **(Figure 15)**. Do not tighten hardware at this time.
10. Line up the hole in the bottom of the Upper Bracket with the hole in the tab on the pinch weld.
  - a. **Models with a weld-nut:** Slide the Bracket over the weld-nut, **(Figure 15)**. Attach the Lower Bracket to the bottom of the body and weld-nut with (1) 8mm x 25mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, **(Figures 20 & 22)**. Leave loose at this time.
  - b. **Models with flat tab and hole:** Insert the 8mm Bolt Plate down through the hole in the Upper Bracket and mounting tab, **(Figures 16 & 17)**. Attach the Lower Bracket to the bottom of the body and Bolt Plate with (1) 8mm Flat Washer and (1) 8mm Nylon Lock Nut, **(Figures 20 & 23)**. Leave loose at this time.
11. Line up the side tab on the Lower Bracket with the threaded hole in the side of the Upper Bracket. Attach the Lower Bracket to the Upper Bracket with (1) 8mm x 25mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, **(Figures 20 & 22)**. Leave loose at this time.
12. Repeat **Steps 1—3** to install the remaining passenger side Bracket. **NOTE:** Cradles on Brackets installed on passenger side will face forward.
  - a. **2017 2500/3500 DEF tank models:** Locate the 2nd tab bracket location along the bottom edge of the body, (pinch weld). Hold the DEF cover in place and mark the 2nd Bracket location onto the cover, **(Figure 18)**. Use a sharp knife or hacksaw blade to carefully cut a slot in the plastic cover to clear the 2nd Bracket, **(Figure 19)**. Remove as little plastic as possible.
13. Repeat **Steps 5 & 6** to install the passenger side Running Board.
14. Once the Running Board has been installed and all hardware fully tightened, reinstall the DEF tank and cover, if equipped, as described in **Steps 8 & 12**.
15. Do periodic inspections to the installation to make sure that all hardware is secure and tight.


**RUNNING BOARDS**  
**07-18 15-3500 SILVERADO/SIERRA REGULAR CAB**  
**INCLUDES DIESEL W/DEF**

To protect your investment, wax product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish. Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Boards.


**Driver/Left Side Installation Pictured**




(Fig 1) Driver side front mounting location




(Fig 3) Driver side rear mounting location



(Fig 5) Driver/left front bracket installed




(Fig 2) Passenger side front mounting location





(Fig 4) Driver side rear mounting location

- (2) 8mm x 25mm Hex Bolts
- (2) 8mm Lock Washers
- (2) 8mm Flat Washers


**Driver/Left Side Installation Pictured**




**(Fig 6) Driver/left rear bracket installed**




**(Fig 9) Driver/left front Bracket installed**




**Passenger/Right Side Installation Pictured**




**(Fig 11) 07-16 Passenger side front pictured with DEF tank cover. Remove (3) hex bolts to remove**




**(Fig 12B) 2017 Passenger side DEF cover**



**(Fig 14) Passenger/right Front Upper Bracket (all models)**




**(Fig 12A) 2017 Passenger side pictured with DEF plastic tank cover. Remove (4) hex bolts to remove plastic cover**



**Remove (2) factory bolts to remove tank straps**


**(Fig 13) 07-16 Passenger side DEF tank and cover**

**Passenger/Right Side Installation Pictured**



**(Fig 15) Slide Upper Bracket over weld nut if equipped-also see Figure 2**


On models with flat tab (see Fig 3 & 4), insert 8mm Bolt Plate (Fig 16) down through Upper Bracket and mounting tab




**Fig 17**



**(Fig 16) 8mm x 35mm Bolt Plate**




**(Fig 18) 2017 Passenger side DEF cover marked for trimming**



**(Fig 19) 2017 Passenger side DEF cut for example only**

**RUNNING BOARDS**  
**07-18 15-3500 SILVERADO/SIERRA REGULAR CAB**  
**INCLUDES DIESEL W/DEF**

**Passenger/Right Side Installation Pictured**




**(Fig 20) Passenger/right Front Upper and Lower Brackets**

**All models use:**  
 8mm x 25mm Hex Bolt  
 8mm Lock Washer  
 8mm Flat Washer

**Models with weld nut on tab (see Fig. 15) use:**  
 8mm x 25mm Hex Bolt  
 8mm Lock Washer  
 8mm Flat Washer



**On models with flat tab and 8mm Bolt Plate (see Fig. 17) use:**  
 8mm Flat Washer  
 8mm Nylon Lock Nut  
 to attach Lower Bracket to Bolt Plate



**(Fig 21) Passenger/right front Bracket installation**

