

**INSTALLATION INSTRUCTIONS  
GRILLE GUARD  
96-98 4RUNNER/98-00 TACOMA**

**PARTS LIST**

**1 – Front Bar**

**2 – Frame brackets**

**12 – 7/16” Flat washers**

**6 – 7/16” x 1-1/4” Hex bolts**

**6 – 7/16” Hex nuts**

**INSTALLATION OF BOTTOM FRAME BRACKET**

Remove tow hooks from front of vehicle.

Using the bolts that held the tow hooks in place (two bolts per hook) attach the mounting bracket as per the diagram below. Do not fasten bolts too tightly to allow you to adjust the alignment.

**INSTALLATION OF FRONT BAR**

Line up the three holes on the lower portion of the front bar with the three holes on the frame mounting brackets (outer edge). Using the 7/16” Hex bolts, nuts and washers, fasten the front bar to the mounting brackets, leaving loose for adjustment.

Once the front bar is attached to the mounting brackets, align until satisfied with fit and balance, and tighten all fasteners.

**NOTE:** It is advisable to re-check all fasteners for tightness after one week.

