


**GRILLE GUARD
2019-2022 MERCEDES BENZ SPRINTER VAN**

PARTS LIST:

1	Grille Guard	2	10mm Nylon Lock Nuts
1	Driver/Left Frame Mounting Bracket	2	8-1.25mm x 40mm Hex Bolts
1	Passenger/Right Frame Mounting Bracket	4	8-1.25mm x 30mm Hex Bolts
1	Driver/Left Center Bracket	2	8-1.25mm x 25mm Button Head Bolts
1	Passenger/Right Center Bracket	8	8mm Lock Washers
2	Top Brackets	6	8mm x 24mm OD x 2mm Flat Washers
2	3/4" OD x 3/8" Tube Spacers	2	8mm x 16mm OD x 1.6mm Flat Washers
6	12-1.75mm x 35mm Hex Bolts	2	4.8 x 30 Screws
12	12mm x 32mm OD x 3mm Flat Washers	2	5mm x 18mm OD x 2mm Flat Washers
6	12mm Lock Washers	1	6mm Hex Wrench
6	12mm Hex Nuts	1	5mm Hex Wrench
2	10-1.5mm x 30mm Button Head Bolts	1	4mm Hex Wrench
4	10mm x 20mm OD x 2mm Flat Washers		



PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. DRILLING IS REQUIRED. ASSISTANCE IS RECOMMENDED.
2. Starting on the Driver/Left side of the vehicle, locate the crossbar at the bottom of the frame, **(Figure 1)**.
 - a. Remove the factory hardware attaching the crossbar on the Driver/Left side. **IMPORTANT:** Only remove the factory hardware one side at a time.
 - b. Select the Driver/Left Mounting Bracket.
 - c. Attach the Bracket to the frame with (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm x 24mm Flat Washers, **(Figures 2 & 3)**. **NOTE:** Determine the slots needed in the Mounting Bracket for model of vehicle. Do not tighten hardware.
3. Repeat **Step 2** to attach the Passenger/Right Mounting Bracket.
4. Next, remove the (2) Torx bolts in the bottom of the opening in the front bumper step area, **(Figure 4)**. **NOTE: Screws may be covered with plastic plugs.** Place a Tube Spacer into the driver/left recess in

**GRILLE GUARD
2019-2022 MERCEDES BENZ SPRINTER VAN**

the bumper cover, **(Figure 5A & 5B)**. Position the Driver/Left Center Bracket over the Tube Spacer. Attach the flat end of the Center Bracket to the Tube Spacer and bumper with (1) 8mm x 40mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm x 24mm STD Flat Washer, **(Figure 6)**. Do not tighten hardware. Repeat this **Step** to attach the Passenger/Right Center Bracket.


5. With assistance, position the Grille Guard up to the outside of the Mounting Brackets. Attach the Grille Guard to the Brackets with (6) 12mm Hex Bolts, (12) 12mm Flat Washers, (6) 12mm Lock Washers and (6) 12mm Hex Nuts, **(Figures 7 & 8)**. Do not tighten hardware.
6. Attach the Driver/Left Center Bracket to the Grille Guard with the included (1) 10mm x 30mm Button Head Bolt, (2) 10mm Flat Washers and (1) 10mm Nylon Lock Nut, **(Figure 9)**. Do not tighten hardware. Repeat this **Step** to attach the Passenger/Right Center Bracket to Grille Guard.
7. Open the hood and remove the screw attaching the top of the grille to the Driver/Left side of the radiator core support, **(Figure 10)**.
8. Select (1) Top Bracket. Attach the Top Bracket to the grille and core support with the included (1) ST4.8 x 45 Philip Screw and (1) 5mm Flat Washer, **(Figures 11 & 12)**. Do not tighten hardware.
9. Line up the outer end of the Top Bracket with the threaded insert in the bottom of the top tube on the Grille Guard. Attach the Bracket to the tube with (1) 8mm x 25mm Button Head Bolt, (1) 8mm Lock Washer and (1) 8mm x 16mm Small Flat Washer, **(Figures 13 & 14)**.
10. Repeat **Steps 8—10** to attach the Passenger/Right Top Bracket.
11. Level and adjust the Grille Guard and tighten all hardware.
12. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.


For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Grille Guard.

For gloss black finishes: Mild soap may be used to clean the Grille Guard.

Driver/Left Side Installation Pictured




(Fig 1) Remove the factory bolts to attach the Mounting Brackets




(Fig 2) Attach the Driver/Left Mounting Bracket to the frame


Driver/Left Side Installation Pictured




(Fig 3) Driver/Left Mounting Bracket attached to the frame



(Fig 4) Remove (2) factory screws (Torx head).
NOTE: Remove plastic plugs covering screws if equipped




(Fig 5A) Tube Spacer




(Fig 5B) Insert Spacer into recess in bumper

8mm x 40mm Hex Bolt
8mm Lock Washer
8mm x 24mm x 2mm Flat Washer




(Fig 6) Attach driver/left Center Bracket to bumper

Driver/Left Side Installation Pictured




- (3) 12mm Hex Bolts
- (6) 12mm Flat Washers
- (3) 12mm Lock Washers
- (3) 12mm Hex Nuts

(Fig 7) Attach the Grille Guard to the Driver/Left Mounting Bracket




(Fig 8) Attach Grille Guard to Frame Brackets




- 10mm x 30mm Button Head Bolt
- (2) 10mm Flat Washers
- 10mm Nylon Lock Nut

(Fig 9) Attach Center Bracket to upright




(Fig 10) Remove factory screw


Driver/Left Side Installation Pictured



(Fig 11) Attach Top Bracket to top of grille



(Fig 12) Top Bracket installed



(Fig 13) Attach Top Bracket to bottom of top tube on Grille Guard



(Fig 14) Top Bracket installed