Installation Instructions

PARTS LIST:			
Qty	Item Description	Qty	Item Description
1	HD Grille Guard	6	10-1.5mm x 35mm Hex Bolts
1	Driver/Left Mounting Bracket	18	10mm x 27mm OD x 3mm Flat Washers
1	Passenger/Right Mounting Bracket	10	10mm Hex Nuts
1	Driver/Left Top Bracket	2	10-1.5mm x 40mm Bolt Plates
1	Passenger/Right Top Bracket	2	M10 Plastic Retainers
1	4mm Allen Wrench	2	10-1.5mm x 35mm Button Head Bolts
1	6mm Allen Wrench	10	10mm Lock Washers



1

Follow (Fig 1 - 10) to remove front clip from vehicle, then remove shutter louvers. After shutter louvers have been removed, reinstall front clip to vehicle.



Driver/left Side Installation Pictured on Fig 4-6



(Fig 2) With air intake out of the way, remove final bolt (arrow) attaching grille. (Passenger Side)



(Fig 4) Remove clips and bolts attaching fender liner. Repeat to passenger side.





(Fig 3) Unplug harnesses (Passenger Side)



(Fig 5) Pull/Tug fender flare straight out to expose bolt. Remove bolt attaching fascia to fender. Repeat to passenger side.





Follow (Fig 11 - 22) to attach Support and Frame Mounting Brackets, then attach Grille Guard to Brackets. Complete each step on both Passenger and Driver side. Ensure all hardware is hand tightened at this point.







Driver/left Side Installation Pictured



(Fig 18) Move under the driver side frame rail. Insert bolt plate into 2nd hole from factory bumper mount. Use Plastic Retainer to keep Bolt Plate in place.



(Fig 20) Attach Driver/Left Frame Mounting Bracket reusing Bolts from Fig 17





(Fig 19) Attach Driver/Left Frame Mounting Bracket to Bolt Plate from Fig 18



(Fig 21) Attached Frame Mounting Bracket to Driver/Left side





Ensure the Grille Guard is level and clearing the Adaptive Cruise Control (Fig 27), then tighten all fasteners. Installation is complete. Do periodic inspections of the installation to make sure that all hardware is secure and tight.



(Fig 27) Ensure the Grille Guard bar does not block or interfere with the Adaptive Cruise Control Sensor (white box)