


**PARTS LIST:**

Qty	Description	Qty	Description
1	Driver/Left EVO3 Running Board	6	8-1.25mm x 35mm Hex Bolts
1	Passenger/Right EVO3 Running Board	6	8mm x 28mm OD x 3mm Large Flat Washers
6	10mm Nut Plates	6	8mm Lock Washers
6	10-1.5mm x 35mm Hex Bolts	6	6-1.0mm x 25mm Hex Bolts
6	10mm x 34mm OD x 3mm Flat Washers	12	6mm ID x 18mm OD x 1.6mm Flat Washers
6	10mm Lock Washers	6	6mm Nylon Lock Nuts



**PROCEDURE:**

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. FACTORY INSTALLED OR AFTERMARKET "ROCK RAILS," SIDE STEPS OR RUNNING BOARDS MUST BE REMOVED. ASSISTANCE IS RECOMMENDED.
2. Start installation on the passenger side of the vehicle. Locate the (3) pairs of holes in the pinch weld along the bottom of the body, (Figure 1). Installation will use the 1st, 4th and 6th mounting holes. If necessary, hold the Running Board up to the mounting locations to help identify the correct mounting holes. Bolt the (3) mounting tabs on the Running Board to the back of the pinch weld using the included (3) 6mm x 25mm Hex Bolts, (6) 6mm Flat Washers and (3) 6mm Nylon Lock Nuts, (Figures 1, 5 & 7). Leave loose at this time.
3. Determine if the vehicle has an open floor panel, (2007-10, Figure 2), or threaded holes in the floor panel, (2010-15, Figure 4), for the top tab on each Bracket.
 

**Models with "open" mounting location:**

  - a. Locate the open holes in the floor panel behind the pinch weld, (Figure 2). Insert (1) 10mm Nut Plate into the large square opening in the floor panel, (Figures 3A & 3B). Line up the threaded nut on the plate with the factory hole and top mounting tab on the Running Board.
  - b. Bolt the top tab on the EVO3 Running Board bracket to the Nut Plate with (1) 10mm x 35mm Hex Bolt, (1) 10mm Lock Washer and (1) 10mm Flat Washer, (Figure 6). Leave hardware loose at this time. Repeat for all mounting locations requiring the 10mm Nut Plate.


**Models with factory 8mm threaded holes in floor panel:**

  - a. Bolt each tab on the Running Board to the threaded hole in the floor panel with (1) 8mm x 35mm Hex Bolt, (1) 8mm Lock Washer and (1) 8mm Flat Washer, (Figures 4 & 7). Leave hardware loose.
4. Repeat **Step 2** and the appropriate **Step 3** as required for all bracket installations.
5. Level and adjust the Running Board and tighten all hardware. Torque the 6mm hardware to 12-14ft-lbs, 8mm hardware to 18-20ft-lbs and the 10mm hardware to 27-30ft-lbs.
6. Repeat **Steps 2—5** for driver side EVO3 Running Board installation.
7. Do periodic inspections to the installation to make sure that all hardware is secure and tight.


**EVO3 RUNNING BOARDS  
2007—15 JEEP WRANGLER 4 DOOR**

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.  
**For gloss black finishes:** Mild soap may be used to clean the EVO3 Running Board.


**Passenger Side Installation Pictured**




**(Fig 1) Locate the (6) mounting holes in the pinch weld. Attach the EVO3 Running Board to the back of the pinch weld**



**(Fig 3A) 10mm Nut Plate**



**(Fig 2) Typical 2007-10 "open" floor panel pictured. Locate the holes in the pinch weld to determine correct hole for 10mm Nut Plate**



**(Fig 3B) Insert 10mm Nut Plate into floor panel**


Passenger Side Installation Pictured




Models with threaded hole in body panel use:  
8mm x 35mm Hex Bolt  
8mm Lock Washer  
8mm Flat washer

6mm x 25mm Hex Bolt  
(2) 6mm Flat Washers  
6mm Nylon Lock Nut

(Fig 4) Example of 2010-13 "closed" floor panel with threaded hole-10mm Nut Plate not required




(Fig 5) Passenger front installation



(Fig 6) Passenger front installation

Models with "open" floor panel using 10mm Nut Plate:  
10mm x 35mm Hex Bolt  
10mm Lock Washer  
10mm Flat Washer

Models with threaded hole in floor panel use:  
8mm x 35mm Hex Bolt  
8mm Lock Washer  
8mm Flat washer



(Fig 7) Passenger rear installation

6mm x 25mm Hex Bolt  
(2) 6mm Flat Washers  
6mm Nylon Lock Nut



Complete Installation