


**EVO3 RUNNING BOARD
05-14 TACOMA DOUBLE CAB**

PARTS LIST:

Qty	Description	Qty	Description
1	Driver/left EVO3 Running Board	12	8-1.25mm x 25mm Hex Bolts
1	Passenger/right EVO3 Running Board	12	8mm x 24mm OD x 2mm STD Flat Washers
		12	8mm Lock Washers




PROCEDURE:

- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY. USE ILLUSTRATION TO IDENTIFY RUNNING BOARDS. ASSISTANCE IS RECOMMENDED.**
- Starting on the driver side front of the vehicle, remove the plastic plugs, (or hex bolts), covering the threaded holes in the body panel, **(Figure 1)**. Repeat to remove the plugs from the center and rear mounting locations, **(Figure 2)**.
- Carefully unwrap the driver side EVO3 Running Board. With assistance, hold the Running Board up in place against the (3) mounting locations. Attach the Running Board to the factory threaded mounting holes with the included (6) 8mm Hex Bolts, (6) 8mm Lock Washers and (8) Flat Washers, **(Figures 3 & 4)**. Do not tighten hardware at this time.
- Level and adjust the Running Board and tighten all hardware. Torque 8mm fasteners to 18-20ft-lbs.
- Repeat **Steps 2—4** for passenger side Running Board installation.
- Do periodic inspections to the installation to make sure that all hardware is secure and tight.


To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Running Board.

Driver Side Installation Pictured




(Fig 1) Driver/left front mounting location

Remove plastic plugs or factory hex bolts (if equipped)



(Fig 2) Driver/left rear mounting location



(Fig 3) Driver/left front Bracket installed

(2) 8mm Hex Bolts
(2) 8mm Lock Washers
(2) 8mm Flat Washers

(2) 8mm Hex Bolts
(2) 8mm Lock Washers
(2) 8mm Flat Washers



(Fig 4) Driver/left rear Bracket installed



Complete Installation