


**STX200 RUNNING BOARD  
2011-14 DODGE DURANGO**

**Parts List:**

2	Bonneville Running Boards (left or right)	12	6mm "T" Bolts
6	Mounting Brackets (left or right)	12	6-1.0mm x 25mm Hex Bolts
6	12-1.75mm x 40mm Bolt Plates	24	6mm x 22mm OD x 2mm Large Flat Washers
6	12mm Plastic Retainers	12	6mm x 18mm OD x 1.6mm STD Flat Washers
6	12mm x 24mm OD x 2.5mm Flat Washers	12	6mm Lock Washers
6	12mm Serrated Locking Flange Nuts	12	6mm Hex Nuts
		12	6mm Nylon Lock Nuts



**PROCEDURE:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**


- Starting at the driver side, locate the (3) pairs of factory holes in the pinch weld, **(Figure 1 & 2)**. Move toward the front pair. Remove the rubber plug filling the oval hole in the bottom of the rocker panel in front of the two holes, **(Figure 3)**. Select (1) 12mm Bolt Plate and (1) 12mm Plastic Retainer. Partially thread the Retainer onto the Bolt Plate, **(Figure 4)**. Insert the Bolt Plate into the oval hole and rotate it 90-degrees to go across the slot, **(Figure 5)**. Thread the Retainer all the way down the Bolt Plate and tight against the body panel. **NOTE:** The Plastic Retainer is designed to prevent the Bolt Plate from falling into the body panel and to aid Bracket installation.
- Select (1) Mounting Bracket, **(Figure 6)**. Attach the Bracket to the Bolt Plate with (1) 12mm x 24mm Flat Washer and (1) 12mm Serrated Flange Nut, **(Figure 7)**. Do not tighten hardware at this time.
- Line up the (2) small slots in the Bracket with the (2) holes in the pinch weld. Bolt the Bracket to the outside of the pinch weld with (2) 6mm x 25mm Hex Bolts, (2) 6mm x 22mm Large Flat Washers, (outside against Bracket), (2) 6mm x 18mm STD Flat Washers, (inside against pinch weld), and (2) 6mm Nylon Lock Nuts, **(Figures 7 & 8)**. Do not tighten hardware at this time.
- Repeat **Steps 1—3** to install the center and rear Brackets, **(Figure 2)**.
- Select (1) Running Board. Locate the slots at the end of the Running Board, **(Figure 9)**. Insert (3) 6mm T-Bolts into each channel. Slide the T-Bolts into the approximate position in line with the (3) Brackets. Carefully place the Running Board in position on top of the Brackets. Slide the T-Bolts forward or back until they line up and drop into the slots on the Brackets.
- Secure the Running Board to the Brackets with (6) 6mm x 22mm Large Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, **(Figure 10)**. Do not tighten hardware.
- Adjust and level the Running Board and tighten all hardware.
- Repeat **Steps 1—7** for passenger/right Running Board installation.
- Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For stainless steel:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

**For gloss black finishes:** Mild soap may be used to clean the Running Board.

Driver Side Installation Pictured



(Fig 1) Driver/left front mounting location pictured



(Fig 2) Driver/left rear mounting location pictured




Fig 3




Fig 4

12mm x 40mm Bolt Plate  
12mm Plastic Retainer

After inserting, rotate Bolt Plate  
90-degrees to go across the slot  
or until Bolt Plate stops





Fig 5



Fig 6

Driver Side Installation Pictured



(1) 12mm x 24mm Flat Washer  
(1) 12mm Flange Nut

Fig 7

6mm x 25mm Hex Bolts  
6mm x 22mm Large Flat Washers (outside)  
6mm x 18mm STD Flat Washers (inside)  
6mm Nylon Lock Nuts




Fig 8


Rear



(Fig 9) Slide 6mm T-Bolts into slots at end of Running Board



Fig 10



Complete Installation